

## HYGIENE+ waste

Ref. AT611

Chrome-plated brass concave grid



### DESCRIPTION

**HYGIENE+ waste**

**Ref. AT611**

Hygienic washbasin waste M1 1/4" with concave grid (no water retention). Free flow, with no central screw (avoids scale deposits and reduces bacterial development).

Polished chrome-plated brass grid, chrome-plated ABS body.

Can be tightened to a minimum of 1mm or maximum of 45mm.

Pre-scored waste: snap-off sections can be removed for models with overflow.

Complies with European standard EN 274-1.

### ADVANTAGES



No central screw, avoids scale and water retention



Can adapt to any washbasin or sink

### TECHNICAL CHARACTERISTICS

**HYGIENE+ waste - Ref. AT611**

Connector	1 1/4"
Finish	Chrome-plated

