

# Hygienic waste without water level

Ref. AT621W

Waste without water level, with membrane



## DESCRIPTION

Hygienic waste without water level

Ref. AT621W

Water-free waste M1 1/4".

Waste with a membrane to prevent bad smells.

No water level: dome with a cup with a membrane which can be removed from above.

Membrane can be cleaned and replaced.

Dome, cup and body made from white polypropylene. Membrane made from silicone.

Evacuation flow rate complies with European standard EN 274: 36 lpm.

Waste can be cut to size.

Not suitable for washbasins with an overflow.

## ADVANTAGES



Maximum hygiene: no water level



Requires minimal space underneath the basin



Easy to maintain: dome can be removed easily

## TECHNICAL CHARACTERISTICS

Hygienic waste without water level - Ref. AT621W

Connector	1 1/4"
Flow rate	complies with European standard EN 274: 36 lpm
Diameter	65mm
Finish	Dome, cup and body made from white polypropylen. Membrane madre from silicone.

